

Moore260 Beam	20CH Mode1	16CH Mode2	DMX Value	Function
Color	1	1	0---4 5---8 9---12 13---17 18---21 22---55 26---29 30--- 34 35--- 38 39---42 43---46 47---51 52---55 56---59 60---63 64---68 69---72 73---76 77---81 82---85 86---89 90---93 94---98 99---102 103---106 107---110 111---115 116---119 120---123 124--- 127 128---255	WHITE WHITE + RED RED RED + ORANGE ORANGE ORANGE + AQUAMARI AQUAMARINE AQUAMARINE + GREEN GREEN GREEN + LIGHT GREEN LIGHT GREEN LIGHT GREEN + LAVEN LAVENDER LAVENDER + PINK PINK PINK + YELLOW YELLOW YELLOW + MAGENTA MAGENTA MAGENTA + CYAN CYAN CYAN + CTO 260 CTO 260 CTO 260 + CTO 190 CTO 190 CTO 190 + CTB 8000 CTB 8000 CTB 8000 + BLUE BLUE BLUE + WHITE CW SlowRotation---->Fast Rotation
Strobe	2	2	0---3 4---103 104---107 108---207 208---212 213---225 226---238 239---251 252---255	Closed Slow Strobe--->Fast Strobe Open SlowPulsation--->Fast Pulsation Open Random Slow Strobe Random Medium Strobe Random Fast Strobe Open
Dimmer	3	3	0---255	Darkness----->Bright
Gobo1	4	4	0---3	WHITE

			4---7 8---11 12---15 16---19 20---23 24---27 28---31 32---35 36---39 40---43 44---47 48---51 52--- 55 56---59 60---63 64---67 68---71 72---113 114---117 118---159 160---166 167---172 173---179 180---185 186--- 191 192---198 199---204 205---211 212---217 218---223 224---230 231---236 237---243 244---249 250---255	GOBO 1 GOBO 2 GOBO 3 GOBO 4 GOBO 5 GOBO 6 GOBO 7 GOBO 8 GOBO 9 GOBO 10 GOBO 11 GOBO 12 GOBO 13 GOBO 14 GOBO 15 GOBO 16 GOBO 17 CW FastRotation----->SlowRotation WHITE CCW SlowRotation----->FastRotation GOBO2 Shake Slow---->Fast GOBO3 Shake Slow---->Fast GOBO4 Shake Slow---->Fast GOBO 5 Shake Slow---->Fast GOBO6 Shake Slow---->Fast GOBO7 Shake Slow---->Fast GOBO8 Shake Slow---->Fast GOBO9 Shake Slow---->Fast GOBO10 Shake Slow---->Fast GOBO11 Shake Slow---->Fast GOBO12 Shake Slow---->Fast GOBO13 Shake Slow---->Fast GOBO14 Shake Slow---->Fast GOBO15 Shake Slow---->Fast GOBO16 Shake Slow---->Fast
Prism	5	5	0---127 128--255	EXCLUDED INSERTED
Prism Rotation	6	6	0---127 128---191 192---255	Position 0° ---->360° CW SlowRotation-----> FastRotation CCW SlowRotation-----> FastRotation
Focus	7	7	0---255	
Forst	8	8	0---255	
Zoom	9	9	0---255	
Pan(X)	10	10	0---255	

Pan(X) Fine	11	11	0---255	
Tilt(Y)	12	12	0---255	
Tilt(Y) Fine	13	13	0---255	
*NULL	14	14	0---255	Undefined
Control	15	15	0---39 40---79 80---100 101---127 128---255	Undefined HALF POWER FULL POWER Undefined Reset ALL
Lamp	16	16	0---25 26---100 101---255	Undefined LAMP OFF LAMP ON
P/T Speed	17		0---128 129---170 171---211 212---255	Fastest----->Slowest Slow Speed ( 1/3 MaxSpeed) Medium Speed ( 1/2 MaxSpeed) Fast Speed (Fastest Speed)
Color Time	18		0---255	Fastest---->Slowset
Dimmer Time Forst Time Prism Time	19		0---255	Fastest---->Slowset
Gobo1 Time	20		0---255	Fastest---->Slowset

\*NULL：表示该通道无作用。

